2500455

Please read all instructions carefully before use and retain for future reference.

CAUTION Do not immerse in water.

Do not cover.

Do not use outdoors.

CAUTION hot surfaces

This product is only suitable for well insulated spaces or occoasional use.

This product has a tip switch, if tipped/knocked over the product will switch off.

ATTENTION This appliance has a thermal cut out switch. The thermal cut out will activate and shut down the appliance should the appliance overheat.
Unplug from the mains and or battery and allow to cool for 15 minutes before re-use.

PRODUCT DISPOSAL INFORMATION For electrical products sold within the European Community, at the end of the electrical product's useful life, it should not be disposed of with household waste. Please recycle where facilities exist. Contact your local authority for details of collection schemes in your area.

In all circumstances:
Do not dispose of in domestic waste.
Do not incinerate.
Do not abandon in the environment.
Do not dispose of WEEE as unsorted municipal waste.

EN

Please read all instructions carefully before use and retain for future reference.

INTENDED USE Only operate the appliance for its intended purpose and within the parameters specified in this manual.
This appliance is for domestic use only. Do not use outdoors or on wet surfaces.
This appliance is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless supervised or given appropriate instruction concerning the product's use by a person responsible for their safety.
The appliance is not intended to be operated by means of an external timer or separate remote-control system.

GENERAL SAFETY Do not allow to be used as a toy. Children should be supervised to ensure they do not play with the appliance.
If the appliance is not functioning properly, has been dropped, damaged, left outdoors, or immersed in liquid, do not use, contact DOMU Brands Customer Services.
Do not use the appliance if any parts appear to be faulty, missing or damaged.
Ensure all parts are securely attached as instructed by this instruction manual before use.

CABLES AND PLUGS Check to ensure your electricity supply matches that shown on the rating plate. This product should only be used as rated. Preferably, the socket outlet should be protected by a Residual Current Device RCD (UK/EU) Ground Fault Indicator (US).
Do not use with a damaged cable or plug. If the supply cable is damaged, it must be replaced by a qualified engineer or authorised service agent in order to avoid a hazard. The use of an extension cable is not recommended.
Do not handle the plug or appliance with wet hands.
Keep the cable away from heated surfaces.
Do not let the cable hang over the edge of the table or countertop where it could be pulled on inadvertently by children or pets.
Do not pull the cable around sharp edges or corners.
Do not leave unattended when plugged in. Unplug from outlet when not in use.
Turn off all controls before unplugging.
Do not unplug by pulling on the cable. To unplug, grasp the plug, not the cable.
Always unplug before performing user maintenance, connecting or disconnecting attachments, or changing accessories.
Ensure the cable is stored safely to prevent hazards.

RISK OF PERSONAL INJURY Always locate your appliance away from the edge of the worktop, on a firm, flat, heat-resistant surface with sufficient space around all sides. Do not insert any objects into openings or cover the appliance.
Do not place any cardboard, plastics or paper inside or on the appliance unless stated in the instructions.
Do not use the appliance near any combustible surfaces. Do not use outdoors or near heat sources.
Take care not to touch any surfaces that may get hot when in use. Take care not to touch any surfaces that may remain hot for a period of time after use.
Never operate the appliance when empty.
Do not overload/overfill the appliance.
When using for the first time your appliance may give off a 'new' smell or vapour. This will dissipate after a few uses. Do not lift or move the appliance whilst in use.
Do not operate continuously for periods longer than those marked on the product or indicated in the instructions.
Ensure the appliance is switched off and unplugged before changing accessories or cleaning.
Use only as described in this manual and with DOMU Brands recommended attachments only.

TECHNICAL SPECIFICATION

Rated Voltage 220V-240V
Rated Power 1800W
Rated Frequency 50/60Hz

COMPONENTS

1. Door.
2. Fire Display.
3. Control Panel.



ATTACH THE HANDLE




On/Off Switch
Flame Effect Switch
I I Switch: Press this to activate High heating (1800W) when pressed with the other switch.
0
I
I
II
Thermostat Dial:
Turn the dial till you hear a click, this will be the current room temperature.
Turn the dial past and when the room has reached its desired temperature turn the dial back until it clicks, the heater will now maintain this heat.
I Switch: Press this to activate low heating (900W).
Dimmer Dial

TROUBLESHOOTING

LIGHT BUT NO HEAT -	Check the Heat Switches are set to the ON position (see operation page)
THE HEATER WILL NOT POWER ON -	Ensure the Heater is switched on and connected to mains power. Activate the Power Selector Switches and Heat Switches. Check the fuse for possible replacment.
HEATER IS NOT HEATING UP -	Check that the Heater is plugged in and switched on at the mains outlet. Ensure the Heater has not entered overheat protection mode. Vents may require cleaning.
THE HEATER HAS BECOME DAMAGED -	Discontinue use immediately and contact DOMU Brands Customer Service.

Model	2500455		
Item	Symbol	Value	Unit
Heat Output			
Nominal Heat Output	P_{nom}	1.8	kW
Minimum Heat Output (indicative)	P_{min}	0.9	kW
Maximum Continious Heat Output	P_{max}	1.8	kW
Auxiliary electricity consumption			
At nominal heat output	EL_{max}	0,012 (fan Motor)	kW
At minimum heat output	EL_{min}	0,012 (fan Motor)	kW
In standy mode	EL_{SB}	0,0	kW

Item	Unit
Type of heat input for Electrical Storage Heaters only (select one)	
Manual heat charge control with integrated thermostat.	N/A
Manual heat charge control with room and/or outdoor temperature feedback.	N/A
Electronic heat charge control with room and/or outdoor temperature feedback	N/A
Fan assisted heat output	N/A
Type of heat output/room temperature control (select one)	
Single stage heat output and no room temperature control	no
Two or more manual stages, no room temperature control	no
With mechanical thermostat room temperature control	yes
With electronic room temperature control	no
Electronic room temperature control plus day timer	no
Electronic room temperature control plus week timer	no
Other control options (multiple selections possible)	
room temperature control with prescence detection	no
room temperature control with open window detection	no
with distance control option	no
with adaptive start control	no
with working time limitation	no
with black bulb sensor	no

Contact Details	DOMU Brands Ltd, 5th & 6th Floor, The Tower, Deva City Office Park, Salford, M3 7BF

EN

DISPOSAL INFORMATION Please recycle where facilities exist. Check with your local authority for recycling advice.

CUSTOMER SERVICE If you are having difficulty using this product and require support, please contact **support@domu.co.uk**

WARRANTY To register your product and find out if you qualify for a free extended warranty please go to **www.vonhaus.com/warranty**.
Please retain a proof of purchase receipt or statement as proof of the purchase date. The warranty only applies if the product is used solely in the manner indicated in the warnings page of this manual, and all other instructions have been followed accurately. Any abuse of the product or the manner in which it is used will invalidate the warranty. Returned goods will not be accepted unless re-packaged in its original packaging and accompanied by a relevant and completed returns form. This does not affect your statutory rights. No rights are given under this warranty to a person acquiring the appliance second-hand or for commercial or communal use.

COPYRIGHT All material in this instruction manual are copyrighted by DOMU Brands.Any unauthorised use may violate worldwide copyright, trademark, and other laws.

THANK YOU

Thank you for purchasing your product/appliance. Should you require further assistance with your purchase, you can contact us at **support@domu.co.uk**
VonHaus is a registered trademark of DOMU Brands Ltd.
Made in China for DOMU Brands. M24 2RW.