

# 1000318.1

# 1500051.1

---



Please read all instructions carefully before use and retain for future reference.



Not suitable for microwave use.



Not dishwasher safe.



Not suitable for oven use.



Materials approved for food use.



## IMPORTANT SAFETY NOTICE

This product is not suitable for use by children or by individuals with physical, sensory, or mental impairments that may limit their ability to operate the equipment safely, unless they have been given supervision or instruction concerning the safe use of the product by a person responsible for their safety.

Improper use may result in serious injury. Always ensure the operator is capable of understanding and following all safety instructions provided in this manual.

**INTENDED USE** Only use the Kitchenware for its intended purpose and within the parameters specified in this manual. This Kitchenware is for domestic use only. Do not use outdoors or on wet surfaces.

The Kitchenware is not intended for use by persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless supervised or given appropriate instruction concerning the product's use by a person responsible for their safety.

**BEFORE FIRST USE** Before using your Kitchenware for the first time, remove all packaging, stickers and labels from the product and store or dispose of safely.

Wash thoroughly in warm, clean, soapy water with a soft cloth and mild detergent. Dry thoroughly using a clean, dry cloth or paper towel.

**GENERAL SAFETY** The Kitchenware is not suitable for use in a dishwasher.

The Kitchenware is not suitable for use in freezers, microwaves or ovens.

Do not subject Kitchenware to sudden temperature changes as this will cause damage.

Sharp knocks, impact or dropping your Kitchenware can cause damage.

Do not use damaged Kitchenware.

**CLEANING & MAINTENANCE** Always wash after each use to minimise stains.

Do not use any metal, harsh abrasive or very stiff cleaning pads/washing up brushes, or abrasive cleaning agents on any of the surfaces. Stubborn stains can be removed by leaving the Kitchenware to soak in warm water and scrubbing gently using a suitable non-abrasive scouring pad. Rinse well with warm water to remove any soap residue and dry thoroughly with a clean cloth to prevent water stains from forming. Store in a cool, dry area out of reach of children.

Refer to the symbols displayed below to ensure suitability for your hob.

**IMPORTANT** Always dry the base of your cookware before cooking.

**IMPORTANT** Always match the base to the hob or heat zone. Gas flames must always be confined to the base area and never allowed to extend up and around the sides of your Cookware. Take care to centre your cookware to get the most from your hob.



Electric Hob




Gas



Ceramic



Halogen



Induction



**DISPOSAL INFORMATION** Please recycle where facilities exist. Check with your local authority for recycling advice.

**CUSTOMER SERVICE** If you are having difficulty using this product and require support, please contact [support@vonhaus.com](mailto:support@vonhaus.com)

**WARRANTY** To register your product and find out if you qualify for a free extended warranty please go to [www.vonhaus.com/warranty](http://www.vonhaus.com/warranty). Please retain a proof of purchase receipt or statement as proof of the purchase date. The warranty only applies if the product is used solely in the manner indicated in the warnings page of this manual, and all other instructions have been followed accurately. Any abuse of the product or the manner in which it is used will invalidate the warranty. Returned goods will not be accepted unless re-packaged in its original packaging and accompanied by a relevant and completed returns form. This does not affect your statutory rights. No rights are given under this warranty to a person acquiring the appliance second-hand or for commercial or communal use.

**COPYRIGHT** All material in this instruction manual are copyrighted by DOMU Brands. Any unauthorised use may violate worldwide copyright, trademark, and other laws.

## THANK YOU

Thank you for purchasing your product/appliance. Should you require further assistance with your purchase, you can contact us at [support@vonhaus.com](mailto:support@vonhaus.com)

VonHaus is a registered trademark of DOMU Brands Ltd. Made in China for DOMU Brands. Unit 30, Stakehill Industrial Estate, Middleton, Manchester M24 2RW.

**EU Authorised Representative:** Authorised Representative Service, 77 Camden Street Lower, Dublin, D02 XE80, Ireland.

**Let's get started!**

Visit our product hub for useful tips and tricks on getting the most out of your new product.

**SCAN ME**

