



# 34L STAINLESS STEEL KITCHEN BIN

## Product Instructions

Product No. 3007772

**vonhaus**

### Let's get started!

Visit our product hub for useful tips and tricks on getting the most out of your new product.

### SCAN ME



Need further help?  
[support@vonhaus.com](mailto:support@vonhaus.com)

See our full range at  
[www.vonhaus.com](http://www.vonhaus.com)

**vonhaus**

## Information

---

### Important Safety Notice

This product is **not suitable for use by children** or by individuals with **physical, sensory, or mental impairments** that may limit their ability to operate the equipment safely, **unless** they have been given supervision or instruction concerning the safe use of the product by a person responsible for their safety.

Improper use may result in serious injury. Always ensure the operator is capable of understanding and following all safety instructions provided in this manual.

### Warnings & Precautions

This recycling bin is for domestic use only. Do not use it for commercial purposes.

Do not use the recycling bin for any purpose not explicitly specified in this user guide.

This product is not a toy. Children should be supervised at all times to ensure they do not play with the recycling bin.

**Warning:** Every effort has been made to smooth any rough edges; however, take care when handling the recycling bin, as some edges may be sharp.

**Caution:** Keep hands and fingers away from the lid and mechanism.

Always rinse items thoroughly before recycling.

Always empty the recycling bin before attempting to move it.

### Cleaning & Maintenance

Keep the recycling bin clean to prevent unpleasant odours. Daily emptying is ideal. Wipe down with cleaning wipes or rinse well with water and mild detergent. Dry thoroughly before use.

Sprinkle some bicarbonate of soda in the bottom of each compartment to absorb moisture and deodorise the recycling bin.

Clean compartments immediately if any waste has spilt.

To deep clean your recycling bin, first rinse thoroughly. Then add 4.5 litres of warm water to a bucket along with a few drops of washing-up liquid and 120 ml (1/2 cup) of bleach. Mix the solution, then use a long-handled mop or brush to clean the inside and outside of the recycling bin. Rinse and dry thoroughly before putting it back in place.

### CUSTOMER SERVICE

If you are having difficulty using this product and require support, please contact [support@vonhaus.com](mailto:support@vonhaus.com)

### WARRANTY

To register your product and find out if you qualify for a free extended warranty please go to [www.vonhaus.com/warranty](http://www.vonhaus.com/warranty)

Please retain a proof of purchase receipt or statement as proof of the purchase date.

The warranty only applies if the product is used solely in the manner indicated in the warnings page of this manual, and all other instructions have been followed accurately.

Any abuse of the product or the manner in which it is used will invalidate the warranty.

### RETURNS

Returned goods will not be accepted unless re-packaged in its original packaging and accompanied by a relevant and completed returns form. This does not affect your statutory rights.

No rights are given under this warranty to a person acquiring the appliance second-hand or for commercial or communal use.

## Information

---

### COPYRIGHT

All material in this instruction manual are copyrighted by DOMU Brands.

Any unauthorised use may violate worldwide copyright, trademark, and other laws.

### THANK YOU

Thank you for purchasing your product/appliance. Should you require assistance with your purchase, please contact us at [support@vonhaus.com](mailto:support@vonhaus.com)

VonHaus is a registered trademark of DOMU Brands Ltd.

Made in China for DOMU Brands Ltd.  
Unit 30, Stakehill Industrial Estate  
Middleton, Manchester, M24 2RW

### EU Authorised Representative

Authorised Representative Service  
77 Camden Street Lower  
Dublin, D02 XE80  
Ireland